



Swimming Pool Heat Pump

User and Service Manual

INDEX

1. Description
2. Transport information
3. Specifications
4. Accessories and options
5. Location and connection
6. Electrical Wiring
7. Start-up of the Heat Pump
8. Troubleshooting
9. Exploded Diagram
10. Maintenance
11. WIFI function- 'Alsavo Pro'APP operation

Thank you for using our swimming pool heat pump for your pool heating, it will heat your pool water and keep the constant temperature when the air ambient temperature is at -12 to 43°C.



ATTENTION: This manual includes all the necessary information for the use and the installation of your heat pump.

- The installer must read the manual and follow the instructions of implementation and maintenance.
- The installer is responsible for the installation of the product and should follow all the instructions of the manufacturer and the regulations in application. Incorrect installation will invalidate the guarantee.
- The manufacturer declines any responsibility for the damage caused by any third party, object ingress and of the errors due to the installation that do not follow the manual guidelines. Any use that is not as intended by the manufacturer will invalidate the guarantee.



WARNING:

Important notice:

- Please always keep the heat pump in a well ventilated place and away from anything which could cause fire.
- Do not braze or weld the pipe if there is refrigerant inside machine. Please do not charge the gas when in a confined space.
- Please always empty the water in heat pump during winter time or when the ambient temperature drops below 0°C, or else the Titanium exchanger will be damaged because of being frozen, in such case, your warranty will be lost.
- Please always cut the power supply if you want to open the cabinet to reach inside the heat pump.
- Please keep the display controller in a dry area to protect the display controller from being damaged by humidity.
- Action of filling gas must be conducted by professional with R32 operating license.


1. Description

1.1 Included with your Heat Pump


- Water connection assembly 48.3 mm (pcs: 2)
- User and service manual
- Draining plug (pcs: 2)
- Water drainage pipes (pcs: 2)
- 10 meters' signal wire (pcs: 1)
- Winter cover (pcs: 1)
- Anti-vibration base (pcs: 4)

1.2 Dimension


Model: Swimmax 07iPS




Model: Swimmax 11iPS/Swimmax 17iPS



Model: Swimmax 20iPS/Swimmax 25iPS



Model: Swimmax 30iPS



2. Transport information

2.1 Delivery of the unit



For the transportation, the heat pumps are fixed on the pallet and covered with a cardboard box.

To protect from any damage, the heat pump must be transferred in its package.

It is the responsibility of the addressee to notify of any damage incurred during delivery within 48 hours.

No responsibility can be taken once the unit has been signed for.

2.2 Stock advice



* The warehouse should be bright, spacious, open, well ventilated, have ventilation equipment and no fire source.

* Heat pumps must be stored and transferred in vertical position in its original packaging. If it is not the case, it cannot be operated until a minimum period of 24H has passed before the unit can have the electrical power turned on.

FORBIDDEN



2.3 Transfer to the final position

* During the unpacking of the product and the transfer from the pallet to the final place of installation, it is necessary to maintain the heat pump in a vertical position.

* Smoking and the use of flames are prohibited near R32 machine.

* Water connection are not to be used as load bearing handles. **The manufacturer would not take the responsibility in case of damage to the water pipes.**

3. Specifications

CE Standard, R32, ABS Cabinet

Model		Swimmax 07iPS	Swimmax 11iPS	Swimmax 17iPS	Swimmax 20iPS	Swimmax 25iPS	Swimmax 30iPS
* Performance at Air 28°C, Water 28°C, Humidity 80%							
Heating capacity	kW	7-2.2	11-2.9	17-3.8	19-4.7	24-5.9	28.5-6.8
Power consumption	kW	1.25-0.14	1.77-0.18	2.83-0.24	3.1-0.29	4-0.37	4.75-0.43
C.O.P.		16-5.6	16-6.2	16-6.0	16-6.0	16-6.0	16-6.0
* Performance at Air 24°C, Water 26°C, Humidity 70%							
Heating capacity	kW	6.9-2.2	10.8-2.8	16.6-3.7	18.8-4.6	23.8-5.8	27.9-6.7
Power consumption	kW	1.25-0.14	1.77-0.18	2.66-0.24	3.1-0.29	3.98-0.37	4.73-0.43
C.O.P.		15.7-5.4	15.7-6.0	15.7-5.8	15.7-5.8	15.7-5.8	15.7-5.8
* Performance at Air 15°C, Water 26°C, Humidity 70%							
Heating capacity	kW	4.7-2.5	7.9-2	11.2-3	14-3.9	17.2-4.5	22.8-5.6
Power consumption	kW	1.02-0.35	1.72-0.28	2.43-0.42	2.78-0.54	3.74-0.63	4.96-0.78
C.O.P.		7.1-4.6	7.2-4.6	7.2-4.6	7.2-4.6	7.2-4.6	7.2-4.6
* General data							
Compressor type		Inverter compressor					
Voltage	V	220~240V / 50Hz or 60Hz / 1PH					
Rated current	A	5.5	7.9	11.8	14	17.7	21
MIN fuse	A	10	16	20	21	25	32
Advised pool volume (with pool cover)	m ³	10-25	15-60	25-85	55-120	65-130	75-180
Advised water flow	m ³ /h	2.5	3.7	4.6	5	8	10
Water pressure drop	Kpa	12	14	15	18	20	25
Heat exchanger		Twist-titanium tube in PVC					
Water connection	mm	40mm/1.5"HP					
Fan quantity		1					2
Ventilation type		Horizontal					
Fan speed	RPM	500-850		550-850	450-650	450-650	(550-850)*2
Power input of Fan	W	6-35		32-110	35-130		(32-110)*2
Noise level(10m)	dB(A)	≤41	≤42	≤43	≤45	≤45	≤49
Noise level(1m)	dB(A)	38-51	40-52	40-54	41-54	42-60	
* Dimension/ Weight							
Net weight	kg	56	73	98	117	128	130
Gross weight	kg	68	78	113	135	146	148
Net dimension	mm	1010*370*559	1060*450*691		1134*446*872		1061*452*1256
Packing dimension	mm	1080*420*732	1121*495*848		1186*495*1011		1127*517*1425

* Above data are subject to modification without notice.


4. Accessories and options

4.1 Accessories list



 <p>Anti-vibration base, 4 pcs</p>	 <p>Draining plug, 2 pcs</p>	 <p>Water drainage pipes, 2 pcs</p>
 <p>10M signal wire, 1 pc</p>	 <p>Water connection assembly, 2 sets</p>	 <p>Winter Cover, 1 pc</p>

4.2 The By-Pass Kit

The By-Pass Kit is the essential accessory for the installation of your heat pump, it is also a tool for the optimization of the heating of the water. The valves allows the optimum flow of water using a manometer to make sure the optimized running of the compressor, see paragraph 5.6 controls of the pressure.



4.3 Accessories Installation

	<p>Anti-vibration bases</p> <ol style="list-style-type: none"> 1. Take out 4 Anti-vibration bases 2. Install them on the bottom of machine.
	<p>Draining plug</p> <ol style="list-style-type: none"> 1. Install the draining plug under the bottom panel 2. Connect with a water pipe to drain out the water. <p>Note: Lift the heat pump to install the draining plug. Never overturn the heat pump, it could damage the compressor.</p>
	<p>Water Inlet & outlet connection</p> <ol style="list-style-type: none"> 1. Install the two joints like the picture shows 2. Screw them onto the water Inlet & outlet connection
	<p>Mains Cable wiring</p> <ol style="list-style-type: none"> 1. Connect the power supply wire through the white hole like the picture shows. 2. Fix the other side on joints inside the electric box.
	<p>Water pump wiring</p> <ol style="list-style-type: none"> 1. Connect the water pump wire through the white hole marked 2. Fix the other side on joints inside the electric box.

5. Location and connection

ATTENTION:

Please observe the following rules when installing the heat pump:

1. Any addition of chemicals must take place in the piping located **downstream** from the heat pump.
2. Always keep the heat pump upright. If the unit has been held at an angle, wait at least 24 hours before applying mains power to the heat pump.


5.1 Heat pump location

The unit will work properly in any desired location as long as the following three items are present:

1. Fresh air
2. Electricity
3. Swimming pool filters

The unit may be installed in virtually any **outdoor** location as long as the specified minimum distances to other objects are maintained (see drawing below). Please consult your installer for installation with an indoor pool. Installation in a windy location does not present any problem at all.


ATTENTION: Never install the unit in a closed room with a limited air volume in which the air expelled from the unit will be reused, or close to shrubbery that could block the air inlet. Such locations impair the continuous supply of fresh air, resulting in reduced efficiency and possibly preventing sufficient heat output.




5.2 Check-valve installation

▲ NOTE

Note: If automatic dosing equipment for chlorine and acidity (pH) is used, it is essential to protect the heat pump against excessively high chemical concentrations which may corrode the heat exchanger. For this reason, equipment of this sort must always be fitted in the piping on the **downstream** side of the heat pump, and it is recommended to install a check-valve to prevent reverse flow in the absence of water circulation. Damage to the heat pump caused by failure to observe this instruction is not covered by the warranty.



5.3 Typical arrangement



This arrangement is only an illustrative example.

 **NOTE**

The factory supplies only the heat pump. All other components, including a bypass if necessary, must be provided by the user or the installer.

ATTENTION:

In order to heat the water in the pool (or hot tub), the filtration pump must be running so the water is circulating through the heat pump. The heat pump will not start up if the water is not circulating.

5.4 Initial operation

After all connections have been made and checked, carry out the following procedure:

1. Switch on the filtration pump. Check for leaks and verify that water is flowing to and from the swimming pool.
2. Connect power to the heat pump and press the On/Off button  on the electronic control panel. The unit will start up after the time delay expires (see below).
3. After a few minutes, check whether the air blowing out of the unit is cooler.
4. When the filtration pump is turned off, the unit should also turn off automatically.
5. Allow the heat pump and the filtration pump to run 24 hours a day until the desired water temperature is reached. The heat pump will stop running at this point +1°C. After this, it will restart automatically (as long as the filtration pump is running) whenever the swimming pool water temperature drops 1 degree below the set temperature (for example, if you set the temperature 28°C, the heat pump will stop when the temperature at 29°C. While it will restart when the temperature of the water down to 27°C)

Depending on the initial temperature of the water in the swimming pool and the air temperature, it may take several days to heat the water to the desired temperature. A good swimming pool cover can dramatically reduce the required length of time.

 **NOTE**

Water Flow Switch:

It is equipped with a flow switch for protecting the HP unit running with adequate water flow rate. It will turn on when the filtration pump runs and shut it off when the pump shuts off.

Time delay - The heat pump has a built-in 3-minute start-up delay to protect the circuitry and avoid excessive electrical contactor wear. The unit will restart automatically after this time delay expires. Even a brief power interruption will trigger this time delay and prevent the unit from restarting immediately. Additional power interruptions during this delay period do not affect the 3-minute duration of the delay.


5.5 Condensation

The air drawn into the heat pump is cooled by the operation of the heat pump for heating the pool water, which may cause condensation on the fins of the evaporator.

NOTE

The amount of condensation may be as much as several liters per hour at high humidity. The condensate will drain from the bottom of the heat pump. This is sometimes mistakenly regarded as a water leak.

5.6 Adjusting the bypass



Please take below steps to adjust the by-pass:

1. Valve 1 wide open. Valve 2 & valve 3 closed.
2. Slowly open valve 2 & valve 3 by half, then close the valve 1 slowly to increase the water flow to valve 2 & valve 3.

If it shows 'ON' or 'EE3' on display, it means the water flow into heat pump is not enough, then you need adjust the valves to increase the water flow through the heat pump.

How to get the optimum water flow:


Please turn on the heat pump under heating function, firstly close the by-pass then open it slowly to start the heat pump (the machine can't start running when the water flow is insufficient).

Continue to adjust the by-pass, at the meantime to check the Inlet water temp. & Outlet water temp., it will be optimum when the difference is around 2 degree.

6. Electrical Wiring


6.1 Inverter swimming pool heat pump wiring diagram

Swimmax 07iPS/Swimmax 11iPS/Swimmax 17iPS/Swimmax 20iPS/Swimmax 25iPS



* Above electrical wiring diagram only for your reference, please subject machine posted the wiring diagram.

Swimmax 30iPS



* Above electrical wiring diagram only for your reference, please subject machine posted the wiring diagram.

6.2 Installation of the display departee

Photo(1)



Photo(2)




Photo(3)



Photo(4)



Photo(5)




- The end with plug connects with the control panel (photo1)
- The other end of the signal wire. (photo2)
- Open the cover of the terminal box and pass through it the cable of the remote screen.(photo3,4)


ATTENTION :

Disconnect: A means to disconnect should be located within sight of and readily accessible from the unit(circuit breaker, fused or un-fused switch). This is common practice on commercial and residential heat pumps. It prevents remotely-energizing unattended equipment and permits turning off power at the unit while the unit is being serviced.

**Connection to pilot the water pump
Dry contact timer connection**



Dry contact pump connection



7. Display Controller Operation

7.1. Guide for operation



7.2 The keys and their operations

7.2.1 button

Press  to start the heat pump unit.

Press  to stop the heat pump unit.

7.2.2 and button

Water temperature setting:

Press  or  to set the water temperature directly.

Heating mode and Auto mode setting range: 6-41°C, Cooling mode setting range: 6-35°C

Press  and  at the same time to check water in temperature, water out temperature and set temperature.

Remark:

1) The buttons are locked if there is no operation on the display for 30 seconds

2) Hold  and  together for 5 seconds to unlock the buttons if necessary.


7.2.3 button

Press  to change the working mode, Powerful, silent and smart. The default mode is smart mode.

7.2.4 button

Press  for 2 seconds to enter secondary page.

Press  and  to select the functions and press  to enter.



7.2.5 Heating/Cooling/Auto mode


Select  and press  to enter, press  and  to choose Heating/ Cooling/ Auto mode, press  again to exit. The default mode is Heating mode.

Note: Under Automatic mode, it is useless to set parameter P1 .

Operation logic of Auto Mode:

T1=Water inlet temperature /Tset= set temperature=28°C

NO	Condition	Current working Status	Water inlet Temperature	Working mode
1	When the heat pump starts	Startup	$27^{\circ}\text{C} \leq T1 < 29^{\circ}\text{C}$	Running heating mode
		Heating mode	$T1 \geq 29^{\circ}\text{C}$, last for 3 minutes	Standby
	When the heat pump is running	Standby	$T1 \geq 30^{\circ}\text{C}$	It switches to cooling mode
		Cooling mode	$T1 = 28^{\circ}\text{C}$, last for 3 minutes	Standby
		Standby	$T1 \leq 27^{\circ}\text{C}$, last for 3 minutes	It switches to heating mode



7.2.6 Parameter checking

Select  and press  to enter, press  and  to check d0-d11 value.

Code	Condition	Scope	Remark
d0	IPM mould temperature	0-120°C	Real testing value
d1	Inlet water temp.	-9°C~99°C	Real testing value
d2	Outlet water temp.	-9°C~99°C	Real testing value
d3	Ambient temp.	-30°C~70°C	flash if Real value<-9
d4	Frequency limitation code	0,1,2,4,8,16	Real testing value
d5	Piping temp.	-30°C~70°C	flash if Real value<-9
d6	Gas exhaust temperature	0°C~C5°C (125°C)	Real testing value
d7	Step of EEV	0~99	N*5
d8	Compressor running frequency	0~99Hz	Real testing value
d9	Compressor current	0~30A	Real testing value
d10	Current fan speed	0-1200 (rpm)	Real testing value
d11	Error code for last time	All error code	

Remark:

d4:Frequency limitation code,

0: No frequency limit;

1:Coil pipe temperature limit;

2: Overheating or overcooling frequency limit; 4:Drive Current frequency limit;

8:Drive voltage frequency limit;

16:Drive high temperature frequency limit

7.2.7 Parameter setting

Select  and press  to enter, press  and  to set P0-P16 value.

Code	Name	Scope	Default	Remark
P0	Mandatory defrosting	0-1	0	0: Default normal operation 1: mandatory defrosting.
P3	Water pump	0-1	0	1: Always running; 0: Depends on the running of compressor
P7	Water temp. calibration	-9~9	0	Default setting: 0
P14	Reset factory setting	0-1	0	
P16	CODE			Related with the model, Not adjustable
P18	Product Range			Only for factory setting

Note: Long press  for 15s to set P14,.

P8,P9,P10,P11,P18 parameter is only for factory setting.


7.2.8 Error code

Select  and press  to check the error code. If the HP is normal,  button is invalid.



7.2.9 Time setting/Timer setting

Select  and press  to enter, press  again to Timer on/Timer off setting.



Press  to enter and  and  to select Timer on or Timer off.

Press  to select on/off and press  or  to set the time. Press  to save the setting.



Long press  for 5 seconds to set the current time.

8.Troubleshooting

8.1 Error code display on wire controller

Malfunction	Error code	Reason	Solution
Inlet water temperature sensor failure T1	PP01	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Outlet water temperature sensor failure T2	PP02	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Heating piping sensor failure T3	PP03	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Gas return sensor failure	PP04	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Ambient temperature sensor failure T5	PP05	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Exhaust piping sensor failure T6	PP06	1. The sensor in open or short circuit 2. The wiring of sensor is loose	1. Check or change the sensor 2.Re-fix the wiring of the sensors
Antifreeze protection in Winter	PP07	Ambient temperature or water inlet temperature is too low	Normal protection
Low ambient temperature protection	PP08	1.Beyond the scope of using environment 2. Sensor abnormality	1. Stop using, beyond the scope of using 2.Change the sensor
Piping temperature too high protection under cooling mode T3	PP10	1. Ambient temperature is too high or the water temperature is too high in cooling mode 2. Refrigeration system is abnormal	1. Check the scope of using 2. Check refrigeration system
T2 water temp. Too low protection under cooling mode	PP11	1. Low water flow 2. T2 temperature sensor abnormal	1. Check filtration pump and waterway system 2. Change T2 temperature sensor
High pressure failure TS4	EE01	1. Ambient temperature is too high 2. Water temperature is too high 3. Water flow is too low Fan motor speed is abnormal or fan motor has damaged	1. Check the water flow or filtration pump 2. Check the fan motor 3. Check and repair the piping system

Malfunction	Error code	Reason	Solution
Low pressure failure TS5	EE02	<ol style="list-style-type: none"> 1. EEV has blocked or pipe system is jammed 2. Motor speed is abnormal or motor has damaged 3. Gas leakage 	<ol style="list-style-type: none"> 1. Check the EEV and piping system Check the motor 2. Through the high pressure gauge to check the pressure value 3. Check refrigeration system
Water flow failure TS1	EE03 Or” ON”	<ol style="list-style-type: none"> 1. Water flow switch is damaged 2. No/ Insufficient water flow. 	<ol style="list-style-type: none"> 1. Change the water flow switch 2. Check the filtration pump or the waterway system
Over heating protection for water temperature (T2) in heating mode	EE04	<ol style="list-style-type: none"> 1. Low water flow 2. Water flow switch is stuck and the water supply is cut off 3. T2 sensor is abnormal 	<ol style="list-style-type: none"> 1. Check the water way system 2. Check the filtration pump or water flow switch 3. Check T2 sensor or replace
T6 Exhaust too high protection	EE05	<ol style="list-style-type: none"> 1.Lack of gas 2.Low water flow 3.Piping system has been blocked 4.Exhaust temp. Sensor failure 	<ol style="list-style-type: none"> 1. Check the high pressure gauge, if too low, fill with some gas 2. Check the waterway system and filtration pump 3. Check the piping system if there was any block 4. Change a new exhaust temp. sensor
Controller failure	EE06	<ol style="list-style-type: none"> 1. Wire connection is not good, or damaged signal wire 2. Controller failure 	<ol style="list-style-type: none"> 1. Check and re-connect the signal wire 2. Change a new signal wire 3. Turn off electricity supply and restart machine 4. Change anew controller
Compressor current protection	EE07	<ol style="list-style-type: none"> 1. The compressor current is too large instantaneously 2. Wrong connection for compressor phase sequence 3.Compressor accumulations of liquid and oil lead to the current becomes larger 4. Compressor or driver board damaged 5. The water flow is abnormal 6. Power fluctuations within a short time 	<ol style="list-style-type: none"> 1. Check the compressor 2. Check compressor phase 3. Check if the power in the normal range 4. Check the phase sequence connection 5. Check the waterway system and filtration pump 6. Check mains power input


Malfunction	Error code	Reason	Solution
Communication failure between controller and main board	EE08	<ol style="list-style-type: none"> Poor signal wire connection or damaged signal wire Controller malfunction 	<ol style="list-style-type: none"> Check and re-connect the signal wire Change a new signal wire Turn off electricity supply and restart machine Change controller
Communication failure between Main control board and Driving board	EE09	<ol style="list-style-type: none"> Poor connection of communication wire The wire is damaged 	<ol style="list-style-type: none"> Check the wire connection Change wire
VDC voltage too high protection	EE10	<ol style="list-style-type: none"> Line voltage is too high Driver board is damaged. 	<ol style="list-style-type: none"> Check if the power is in the normal range Change driver board or main board
IPM module protection	EE11	<ol style="list-style-type: none"> Data mistake Wrong compressor phase connection Compressor liquid and oil accumulation lead to the current becomes larger Compressor or driver board damaged 	<ol style="list-style-type: none"> Program error, turn off electricity supply and restart after 3 minutes Change driver board Check compressor sequence connection
VDC voltage too low protection	EE12	<ol style="list-style-type: none"> Mother line voltage is too low Driver board is damaged. 	<ol style="list-style-type: none"> Check if the power is in the normal range Change driver board
Input current over high protection.	EE13	<ol style="list-style-type: none"> The compressor current is too large momentary The water flow is abnormal Power fluctuations within a short time Wrong PFC inductor 	<ol style="list-style-type: none"> Check the compressor Check the waterway system Check if the power is in the normal range Check if the correct PFC inductor is used
IPM module thermal circuit is abnormal	EE14	<ol style="list-style-type: none"> Output abnormality of IPM module thermal circuit Fan motor is abnormal or damaged Fan blade is broken 	<ol style="list-style-type: none"> Change a driver board Check if the motor speed is too low or fan motor damaged, change it Change the fan blade

Malfunction	Error code	Reason	Solution
IPM module temperature too high protection	EE15	<ol style="list-style-type: none"> 1. Output exception of IPM module thermal circuit 2. Motor is abnormal or damaged 3. Fan blade is broken 	<ol style="list-style-type: none"> 1. Change a driver board 2. Check if the fan motor speed is too low or fan motor damaged, change it 3. Change the fan blade
PFC module protection	EE16	<ol style="list-style-type: none"> 1. Output exception of PFC module 2. Motor is abnormal or damaged 3. Fan blade is broken 4. Input voltage leap, input power is abnormal 	<ol style="list-style-type: none"> 1. Change a driver board 2. Check if the motor speed is too low or fan motor damaged, change it 3. Change the fan blade 4. Check the input voltage
DC fan motor failure	EE17	<ol style="list-style-type: none"> 1. DC motor is damaged 2. Main board is damaged 3. The fan blade is stuck 	<ol style="list-style-type: none"> 1. Detect DC motor, replace with a new one 2. Change a new main board 3. Find out the barrier and work it out
PFC module thermal circuit is abnormal	EE18	The driver board is damaged	<ol style="list-style-type: none"> 1. Change a new driver board 2. Check if the fan motor speed is too low or fan motor damaged, change it
PFC module high temperature protection	EE19	<ol style="list-style-type: none"> 1. PFC module thermal circuit output abnormal 2. Motor is abnormal or damaged 3. Fan blade is broken 4. The screw in the driver board is not tight 	<ol style="list-style-type: none"> 1. Change a new driver board 2. Check if the motor speed is too low or fan motor damaged, change it 3. Change the fan blade 4. Check if the screw is loose
Input power failure	EE20	The supply voltage fluctuates too much	Check whether the voltage is stable


Malfunction	Error code	Reason	Solution
Software control exception	EE21	1.Compressor runs out of step 2. Wrong program 3. Impurity inside compressor causes the unstable rotate speed	1. Check the main board or change a new one 2. Enter correct program
Current detection circuit failure	EE22	1. Voltage signal abnormal 2. Driver board is damaged	1. Check the main board or change a new one 2. Change a new driver board
Compressor start failure	EE23	1. Main board is damaged 2. Compressor wiring error or poor contact or unconnected 3. Liquid accumulation inside 4. Wrong phase connection for compressor	1. Check the main board or change a new one 2. Check the compressor wiring according to the circuit diagram Check the compressor or change a new one
Ambient Temperature device failure on Driver board	EE24	Ambient Temperature device failure	Change driver board or main board
Compressor phase failure	EE25	Compressors U, V, W are connected to one phase or two phases.	Check the actual wiring according to the circuit diagram
Four-way valve reversal failure	EE26	1. Four-way valve reversal failure 2. Lack of refrigerant (no detect when T3 or T5 malfunction)	1. Switch to Cooling mode to check the 4-way valve if it has been reversed correctly 2. Change a new 4-way valve 3. Fill with gas
EEPROM data read malfunction	EE27	1. Wrong EEPROM data in the program or failed input of EEPROM data 2. Main board failure	1. Re-enter correct EEPROM data 2. Change a new main board
The inter-chip communication failure on the main control board	EE28	Main board failure	1. Turn off electricity supply and restart it 2. Change a new main board

Remarks:

1. In heating mode, if the water out temperature is higher than the set temperature over 7°C, controller displays EE04 for water over-heating protection.
2. In cooling mode, if the water out temperature is lower than the set temperature over 7°C, controller displays PP11 for water over-cooling protection.



EE04 Water Overheating Protection



PP11 Water Overcooling Protection

For example as below:

Mode	Output water temperature	Set point temperature	Condition	Malfunction
Heating mode	36°C	29°C	$T_{out} - T_{set} \cong 7^{\circ}\text{C}$	EE04 Overheating protection for water temperature (T2)
Cooling mode	23°C	30°C	$T_{set} - T_{out} \cong 7^{\circ}\text{C}$	PP11 Too low protection for water temperature (T2)

Water pump running logic and error code EE03 or 'ON'.

There are two options for water pump running.

Option 1: Water pump starts or stops in relation to heat pump operation.

Water pump starts 60s before compressor, water pump start 30s and then detect the water flow switch. When the heat pump meet the requirement of standby mode, water pump will stop 5mins after compressor stops. Water flow switch won't be detected in 1H standby of heat pump. Even if the water flow switch is manually removed, the EE03/ON error will not be reported. Water pump will restart to running for 5mins to check the water temp. when the standby time is over 1 hours.

HP working mode	Condition (Tset:Setting water temp. T1: Inlet water temp.)	Example: Tset = 28°C,	Water pump working logic
Heating mode	$T1 \geq Tset - 0.5$, and last for 30 min	$T1 \geq 27.5^{\circ}\text{C}$, last for 30 minutes	If heat pump enter standby mode for 1 hours, water Pump will start 5mins to check whether $T1 > Tset - 1$, if so, heat pump will go into standby again. If $T1 \leq Tset - 1$, heat pump will restart.
Cooling mode	$T1 \leq Tset + 0.5$, And last for 30 min	$T1 \leq 28.5^{\circ}\text{C}$, last for 30 minutes	If heat pump enter standby mode for 1 hours, water Pump will start 5mins to check whether $T1 < Tset + 1$, if so, heat pump will go into standby again. If $T1 \geq Tset + 1$, heat pump will restart.

In this case, it is unnecessary to deal with Error code 'ON' if 'ON' occurs in 1 hours standby period.

Option 2

No matter when the heat pump is on (running or standby), water pump will always be running.

Water pump will run for 1 minute after manually turn off.


8.2 Other Malfunctions and Solutions (No display on wire controller)

Malfunctions	Observing	Reasons	Solution
Heat pump is not running	LED wire controller no display.	No power supply	Check cable and circuit breaker if it is connected
	LED wire controller. Displays the actual time.	Heat pump under standby status	Startup heat pump to run.
	LED wire controller displays the actual water temperature.	1. Water temperature is reaching to setting value, HP under constant temperature status. 2. Heat pump just starts to run. 3. Under defrosting.	1. Verify water temperature setting. 2. Startup heat pump after a few minutes. 3. LED wire controller should display "Defrosting".
Water temperature is cooling when HP runs under heating mode	LED wire controller displays actual water temperature and no error code displays.	1. Choose the wrong mode. 2. Figures show defects. 3. Controller defect.	1. Adjust the mode to proper running 2. Replace the defect LED wire controller, and then check the status after changing the running mode, verifying the water inlet and outlet temperature. 3. Replace or repair the heat pump unit
Short running	LED displays actual water temperature, no error code displays.	1. Fan NO running. 2. Air ventilation is not enough. 3. Refrigerant is not enough.	1. Check the cable connections between the motor and fan, if necessary, it should be replaced. 2. Check the location of heat pump unit, and eliminate all obstacles to make good air ventilation. 3 Replace or repair the heat pump unit.
Water stains	Water stains on heat pump unit.	1. Concreting. 2. Water leakage.	1. No action. 2. Check the titanium heat exchanger carefully if it is any defect.
Too much ice on evaporator	Too much ice on evaporator.		1. Check the location of heat pump unit, and eliminate all obstacles to make good air ventilation. 2. Replace or repair the heat pump unit.

9.Exploded Diagram

7. Exploded Diagram


Mode: Swimmax 07iPS



Model : Swimmax 07iPS

No.	Part name	No.	Part name
1	Top cover	29	High pressure switch
2	Ambient temp. sensor T5-TH1	30	Discharge pipe
3	Ambient temp. sensor clip	31	4-way valve to exchanger
4	Back grill	32	Low pressure switch
5	Evaporator	33	Main capillary
6	Evaporator temperature sensor T3-TH2	34	Pipe
7	Clip	35	Pipe
8	Sensor holder	36	4 way valve
9	Electric box cover	37	Pipe
10	Top frame	38	Needle valve
11	PCB	39	Titanium heat exchanger
12	Pilar	40	Drainage plug
13	Electric box	41	Water inlet temp. sensor T1-TH6
14	Left panel	42	Exchanger temperature sensor clip
15	Isolation panel	43	Right panel
16	Reactor	44	Terminal board
17	Compressor	45	Pressure gauge
18	Fan motor support	46	Clip
19	Base tray	47	Terminal board cover
20	Fan motor	48	5-ways terminal block
21	Fan blade	49	Water outlet temp. sensor T2-TH5
22	Front panel	50	Red rubber ring
23	Waterproof controller box	51	Evaporator pipe
24	Controller box cover	52	Distribution piping
25	Controller	53	Blue rubber ring
26	Front grill	54	Water connection sets
27	Discharge temp. sensor T6-TH3	55	Red rubber ring
28	Gas return piping	56	WIFI Module


Model: Swimmax 11iPS/ Swimmax 17iPS



Spare parts list: Swimmax 11iPS/ Swimmax 17iPS

No.	Part name	No.	Part name
1	Top cover	31	Compressor
2	Ambient temp. sensor T5-TH1	32	Water inlet temp. sensor T1-TH6
3	Ambient temp. sensor clip	33	Exchanger temperature sensor clip
4	Back grill	34	Titanium heat exchanger
5	Evaporator	35	Drainage plug
6	Evaporator temperature sensor T3-TH2	36	Right panel
7	Sensor holder	37	Pressure gauge
8	Clip	38	Clip
9	4 way valve	39	5-ways terminal block
10	Discharge temp. sensor T6-TH3	40	Terminal board cover
11	Pillar	41	Terminal board
12	Fan motor support	42	Water outlet temp. sensor T2-TH5
13	Top frame	43	Water flow switch
14	Reactor	44	Gas return piping
15	Isolation panel	45	Low pressure switch
16	Left panel	46	High pressure switch
17	Fan motor	47	Discharge pipe
18	Fan motor assemble	48	EEV
19	Fan blade	49	Pipe
20	Front panel	50	Pipe
21	Front grill	51	Pipe
22	Waterproof controller box	52	Pipe
23	Controller box cover	53	Evaporator pipe
24	Controller	54	Back panel
25	Base tray	55	Distribution piping
26	Electric box cover	56	Blue rubber ring
27	PCB	57	Water connection sets
28	Electric box	58	Red rubber ring
29	Wifi module	59	Needle valve
30	Compressor heating resistor		


Model:Swimmax 20iPS/Swimmax 25iPS



Spare parts list: Swimmax 25iPS

No.	Part Name	No.	Part Name
1	Top cover	32	Pressure gauge
2	Back grill	33	Clip
3	Evaporator	34	Terminal board cover
4	Pillar	35	5-ways terminal block
5	Top frame	36	Right panel
6	Isolation panel	37	Water outlet temp. sensor T2-TH5
7	Reactor	38	Water flow switch
8	Fan motor support	39	High pressure switch
9	Fan motor	40	Discharge temp. sensor T6-TH3
10	Fan blade	41	Clip
11	Left panel	42	Low pressure switch
12	Front panel	43	Gas return piping
13	Back grill	44	Discharge pipe
14	Waterproof controller box	45	Sensor holder
15	Pipe	46	Pipe
16	Controller box cover	47	Evaporator pipe
17	Electric box cover	48	Distribution piping
18	Base tray	49	Evaporator temperature sensor T3-TH2
19	Controller	50	Back panel
20	Compressor	51	Blue rubber ring
21	PCB	52	Water connection sets
22	Pipe	53	Red rubber ring
23	Liquid Reservoir	54	Pipe
24	Wifi module	55	4 way valve
25	Electric box	56	EEV
26	Filter	57	Pipe
27	Drainage plug	58	Pipe
28	Exchanger temperature sensor clip	59	Ambient temp. sensor T5-TH1
29	Water inlet temp. sensor T1-TH6	60	Ambient temp. sensor clip
30	Terminal board	61	Needle valve
31	Titanium heat exchanger		

Model: Swimmax 30iPS



Spare parts list: Swimmax 30iPS

No.	Part Name	No.	Part Name
1	Top cover	40	Evaporator pipe
2	Ambient temp. sensor T5-TH1	41	Back panel
3	Ambient temp. sensor clip	42	Needle valve
4	Back grill	43	Gas return piping
5	Evaporator	44	Low pressure switch
6	Evaporator temperature sensor T3-TH2	45	Pipe
7	Clip	46	Discharge pipe
8	Sensor holder	47	Pipe
9	Distribution piping	48	4 way valve
10	Isolation panel	49	High pressure switch
11	Reactor	50	Discharge temp. sensor T6-TH3
12	Pillar	51	Pipe
13	Top frame	52	Pipe
14	Fan motor support	53	Pipe
15	Front panel support	54	EEV
16	Fan motor	55	Filter
17	Fan blade	56	Pipe
18	Fan motor assemble	57	Water flow switch
19	Waterproof controller box	58	Water outlet temp. sensor T2-TH5
20	Left panel	59	Exchanger temperature sensor clip
21	Front grill	60	Titanium heat exchanger
22	Front panel	61	Water connection sets
23	Controller box cover	62	Blue rubber ring
24	Controller	63	Connector sealing ring
25	Compressor	64	Water inlet temp. sensor T1-TH6
26	Compressor damping feet	65	Drainage plug
27	Liquid Reservoir	66	Red rubber ring
28	Compressor heating resistor	67	Sealing ring
29	Base tray	68	Electric box cover
30	Handler panel	69	Driver board
31	Terminal board support	70	Relay
32	Right panel	71	Filter board
33	3-ways power terminal block	72	Magnetic ring
34	Pressure gauge	73	PCB
35	Clip	74	Electric box
36	Terminal board support	75	Magnetic ring
37	3-ways terminal block	76	Wifi module
38	Terminal board cover	77	Scale panel
39	Rubber block		

10. Maintenance

- (1) You should check the water supply system regularly to avoid air entering the system and creation of low water flow, because it would reduce the performance and reliability of HP unit.
- (2) Clean your pools and filtration system regularly to avoid the damage of the unit.
- (3) Only a qualified technician is authorized to operate the cooling system pressure. You should drain the water from the heat pump if it will stop running for a long time (especially during the winter season or when the ambient temperature drops below 0°C).
- (4) Check the water levels before the unit start after a long break in usage.
- (5) When the unit is running, there will be condensate water discharging from the bottom of the unit. This is normal.

11. WIFI function- 'Alsavo Pro'APP operation





11.1 operation

1. Firstly download "Alsavo Pro" APP from App store or Google play in your smart phone.
Parameter P17=1 (WIFI function) could be auto recognition in the controller if the machine already install WIFI PCB.
2. Open "Alsavo Pro" APP, click "+" on the upper left and select "New device". Then Click "Next" and enter the current WIFI password to connect. Press "⏻" 5S on the display no matter it's ON or OFF. Or you can press "⏻" 5S on the display first, then enter the current WIFI password. The display will show F1 1,F1 2, until F1 6, which means the connect is OK.


If the connection fails, the APP will indicate "Failed to connect device".

"Nickname and password" interface only appear one time when a new heat pump is connected successfully. You can name and add encrypt this unit. (This interface may be missing if the wifi network is not steady. You will miss the chance to name and encrypt it. In this case, default password "123456" is available.)

If someone's APP is in the same WIFI network as yours, his APP could automatically identify your heat pump. And he can operate your heat pump after inputting your password.



3. The main interface



1) Turn ON/OFF



Click “” to turn on or off heat pump.

2) Switch mode

There are three modes (Auto mode, cooling or heating) for the invertboost unit. Click its icons to switch (Auto

mode , heating , cooling )




3) Timer setting



Click , it turns . Timer on and off will be activated together. Then choose desired time in “timer on” and “timer off”, lastly click “OK” to confirm.





Click “” again to cancel.



4) Parameter checking and setting



Click Parameter , then enter the password "0757".



Parameter Query		Default
Water In		22 °C
Water Out		22 °C
Heating piping temperature		22 °C
Limited frequency code		0
Ambient temperature		23 °C
Exhaust temperature		21 °C
Actual steps of electronic expansion valve		350
IPM module temperature		25 °C
Compressor running frequency		0Hz
Compressor current		0A
DC fan motor speed		0RPM
Parameter Setting		Range
Water Pump Operating Mode		0 (0~1)
Water Temperature Calibration	8.5 °C	(-9.9 °C ~ 9.9 °C)
Re-set to factory default setting		


Parameter setting:

- (1) There are 2 modes optional for water pump operation (1: Always running, 0: Depends on the running of compressor)
- (2) Inlet water temperature calibration. (-9.0 to 9.0 °C)
- (3) Temperature unit: °C or °F.
- (4) When you want to reset to factory default setting, tips as below pop up .



5) Switch running modes

In heating or cooling mode, there are 3 running modes(Silent, Smart, Powerful) for options



While in Auto mode, its default running mode is Smart.

6) Malfunction



If error occurs, the malfunction icon turns red. Click it to check the error.

← Malfunction Alsavo Pro	
Error code	Malfunction
PP01	Inlet water temperature sensor failure
PP02	Outlet water temperature sensor failure
PP03	Heating coil pipe sensor failure
PP04	Gas return sensor failure
PP05	Ambient temperature sensor failure
PP06	Exhaust temperature sensor failure
PP07	Anti-freezing protection in Winter
PP08	Low ambient temperature protection
PP10	Coil pipe temperature too high protection under Cooling mode
PP11	T2 too low water temperature protection under cooling mode
EE01	High pressure failure
EE02	Low pressure failure
EE03	Water flow failure
EE04	Water temperature overheating protection under heating mode
EE05	Exhaust temperature too high failure
EE06	Controller malfunction or communication failure
EE07	Compressor current protection
EE08	Communication failure between controller and PCB
EE09	Communication failure between PCB and driver board
EE10	VDC Voltage too high protection
EE11	IPM Module protection
EE12	VDC Voltage too low protection
EE13	Input current too strong protection
EE14	IPM module thermal circuit is abnormal
EE15	IPM module temperature too high protection
EE16	PFC module protection
EE17	DC fan failure
EE18	PFC module thermal circuit is abnormal
EE19	PFC module high temperature protection
EE20	Input power failure
EE21	Software control failure
EE22	Current detection circuit failure
EE23	Compressor start failure
EE24	Ambient temperature device failure on Driving board
EE25	Compressor phase failure
EE26	4-way valve reversal failure
EE27	EEPROM data reading failure in Transfer board
EE28	The inter-chip communication failure on the main control board

7) Temperature setting



You can set the target water temperature by adjusting the slider or press “” or “”. The setting water temperature on the controller display correspondingly changes after letting go. When the setting water temperature on the display changes, it will be synchronously updated to the APP.

8) Check device information

In the main interface, click the upper right “Alsavo Pro”. The Device information will show up.



9) Revise the heat pump info in the homepage



Click “”, you could rename, change its password and delete the device.

